



BACKED
by **BAYER™**

IMPORTANT NOTICE BUILDING CONTRACTORS

Australian Standard 3660.1,2000 Termite management Part 1: New Building Work: requires a 75 mm inspection zone below the level of the termite barrier. Whilst there are some exceptions, the time to address this situation is during construction, but most importantly, **BEFORE EXTERNAL FINISHES** are completed eg. pathways, rendering, downpipes, decking, patios, piers, steps, access ramps, nib walls installed directly to the structure, landscaping etc.

URGENT: CHECK LIST

- Will the pathways allow for a 75 mm inspection zone? YES
- Will the patios have the necessary inspection zone? YES
- Will the entry have the required inspection zone? YES
- Will abutting walls / attachments bridge the barrier? NO
- Will external steps bridge the barrier? NO
- Will external decking bridge the barrier? NO
- Will driveway slabs compromise the barrier? NO
- Will landscaping compromise the barrier? NO
- Will carports, hot water system effect the barrier? NO
- Will downpipes compromise the barrier? NO
- Will internal step down installations comply? YES

Refer to Sections 3.5 & 3.6 of AS 3660.1,2000

If your answers do **not agree** with all of the above, please contact your Accredited Kordon Installer **immediately**. Given the correct time frame, they can address any situation to ensure the completed building has a Kordon Termite Barrier, which complies with the AS3660.1 and the B.C.A.



Bayer Environmental Science

Ph. 1800 634 913 www.kordontmb.com.au
391-393 Tooronga Road, East Hawthorn Vic 3123.
A Business Group of Bayer Crop Science ABN 87 000 226 022

Installer Contact Details

SOME EXAMPLES WHERE KORDON TERMITE BARRIER INSTALLATION HAS BEEN COMPROMISED BY EXTERNAL FINISHES



Solution: Install Kordon to detail kd 041b before installing pathway paving



Solution: Install Kordon to detail kd 041b before pouring driveway paving



Solution: Install Kordon to detail kd 041b between brickwork and structure



Solution: Install Kordon to the vertical joint before pouring pathway



Solution: Install Kordon to the vertical before pouring entry



Kordon example installation of detail kd 041b which allows maintenance of the termite inspection zone